

# JTAG Board

- [Photo](#)

## Board Compatibilty

EposMote3 Regular	Yes	EposMote3 Black	Yes
-------------------	-----	-----------------	-----

## Board Connections

There are 4 sets of connector in JTAG Board. Exp1 and Exp2 are the regular connections with EM3/EM3+ board. The JTAG connector is used to link with a regular 20 pins ARM debugger/emulator. P1 and P2 are connector with .1 pitch to externalize the Exp1 and Exp2 input/output pins. With P3 is possible to connect a FTDI (UART - USB) converter board.

### P1 and P2 connections

### P3 connections

## Version 0.1 Issues

Two connections are wrong in the v0.1, J\_TDO and J\_TDI. Both tracks must be cut and crossed.

- [Photo](#)